



Art. Nr. Art. No.	Bezeichnung Specification	Inhalt kg Capacity kg	Abmessung mm Dimension mm
1550	FIAP Pendelfütterer	3	A:233 B:206 C:311
1551	FIAP Pendelfütterer	10	A:315 B:270 C:360
1552	FIAP Pendelfütterer	20	A:385 B:315 C:460
1553	FIAP Pendelfütterer	40	A:470 B:380 C:670
1554	FIAP Pendelfütterer	60	A:590 B:480 C:840



GB

## Information about this operating manual

Please read the operating instructions and familiarise yourself with the unit prior to using it for the first time. Adhere to the safety information for the correct and safe use of the unit.

## Intended use

FIAP Pendulum Feeder, called in the further device is intended for use as fish feed machine.

## Use other than that intended

Danger to persons can emanate from this unit if it is not used in accordance with the intended use and in the case of misuse. If used for purposes other than that intended, our warranty and operating permit will become null and void.

## CE Manufacturer's Declaration

We declare conformity in the sense of the EC directive.

The following harmonised standards apply: EN 61058-1, EN 60669-2-1.

## Safety information

FIAP has manufactured this unit according to the highest quality standards and the valid safety regulations. Despite of the above, hazards for persons and assets can emanate from this unit if it is used in an improper manner or not in accordance with its intended use, or if the safety instructions are ignored.

**For safety reasons, children and young persons under 16 years of age as well as persons, who cannot recognise possible danger or who are not familiar with these operating instructions, are not permitted to use the unit!**

Please keep these operating instructions in a safe place! Also hand over the operating instructions when passing the unit on to a new owner. Ensure that all work with this unit is only carried out in accordance with these instructions. The combination of water and electricity can lead to danger for life and limb, if the unit is incorrectly connected and misused.

Do not use the unit in or under water. Never open the unit housing or its attendant components, unless this is explicitly mentioned in the operating instructions. Compare the electrical values of the power supply with those on the type plate on the packing or on the unit itself. For your own safety, consult a qualified electrician when you have questions or encounter problems! Protect the connection cable when burying to avoid damage. Only use cables approved for outside use. Protect the plug connection from moisture.



FIAP Pendulum Feeder is operated without current vi adaptor with a pendular system. The discharge pipe's mechanical turning allows for steplessly adjusting the fodder quantity. The required amount of feedingstuffs depends on the fish activity. As needed, the container can be filled with the fodder required for several days (3, 10, 20, 40 or 60 kg). Under water contact with pendulum will release the feedingstuffs (pellets in a size from 2 to 10 mm). FIAP Pendulum Feeder is thus suitable for the consistent feeding of all fish species, and is available in 5 different versions.

As accessories, we offer retaining ring, swivel arm, and pipe penetration. FIAP Pendulum Feeder serves to optimize your fish farm's feedingstuffs ratio.

## Cleaning

To ensure a good continuity with the feedings, FIAP Pendulum Feeder during the season now and again to be cleaned. Remove with a small brush the dust and food residues from the FIAP Pendulum Feeder Container and System.

## Store / hibernate

Clean for the winter and dry the food container and keep the equipment until the following spring in a dry and frost-free place.

## Disposal

The device should be disposed of in accordance with national law. Check with your dealer.

